

● *Blueair*

User manual



SCAN FOR SUPPORT

Blue
Pure 511

Safety information

Blue Pure 511

Product name	Model number
Blue Pure 511	3131000000

Blue Pure 511 air purifier is an electrical appliance for indoor use only, take the necessary precautions to reduce the risk of fire, electric shock or injury.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Supervise children to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Always disconnect the appliance from the power supply before maintenance.
- If your Blueair appliance is found to be defective, we will replace it with the same or a similar model at no cost, per the warranty terms. Please use caution attempting repairs yourself, as this presents the danger of electrical shock or injury.
- Ensure that the power cable and the power plug are not at risk of getting damaged.
- If the appliance is damaged or malfunctions, turn it off, disconnect it from the power supply and contact Blueair.
- The power plug must be firmly inserted in the power socket.

- When disconnecting the unit from the power supply, do not pull on the power cord, pull on the power plug.
- Use the power cable provided with your Blueair air purifier to plug directly and firmly into an appropriate, electrical outlet.
- Do not use an extension cord or a power strip. Refer to the rating label on your appliance.
- Do not use the included power cord for anything else but the appliance.
- Do not allow objects to enter or block the air inlets and air outlets as this can cause electric shock or damage the appliance.
- Do not place any objects on top of or directly against the appliance.
- Do not sit on, stand, climb onto or hang from the appliance.
- Keep the appliance, including the power cable, at a safe distance from heated surfaces and open fire.
- Keep the appliance and power plug away from water and other liquids.
- Keep the appliance and power plug away from chemicals such as pesticides and deodorants.
- Place the air purifier on the floor or a stable surface to prevent tipping.
- Do not use the appliance outdoors or in wet environments such as bathrooms, laundry rooms or pool areas.
- Always turn off and disconnect the appliance from the power supply before moving the unit, changing filters, cleaning or carrying out maintenance procedures.
- Never clean with gasoline, chemical solvents, or corrosive materials as these agents may damage the air purifier.

Regulatory information

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

Product map

A One touch button

B Air outlet


C Fan motor

D Filter shelf ring (Reusable. Do not dispose)


E Main filter

F Washable pre-filter, outer fabric

G Hidden cord sleeve



Getting started



Plug and play

Plug the power cable into a wall outlet and press the center one touch button to turn the air purifier on and adjust the fan speed mode.

Set it and forget it



Night mode

Press 1 time
Low fan speed
Dim lights



Everyday mode

Press 2 times
Medium speed



Boost mode

Press 3 times
High speed



Off

Press 4 times

Cleaning your washable pre-filter

Clean your pre-filter regularly when you see dust or dirt. Vacuum the exterior of the fabric with a soft brush attachment. If the pre-filter requires a deeper clean, wash according to the instructions on the pre-filter's label. Hang to dry.

Step 1

Turn the air purifier off and unplug it.
Rotate the top counter-clockwise to unlock and remove it.



Step 2

Open the pre-filter panel and remove the pre-filter.




Step 3

Wash according to instructions on the pre-filter's label.




Step 4

Place the pre-filter back. Adjust the pre-filter to hide the power cord in the back.



Step 5

Push the top cylinder down, rotate it clockwise to lock it.




Important! Press the Velcro strips together on the pre-filter before machine wash.

Maintenance information

Important! Disconnect the air purifier from the power supply before maintenance.


Changing your main filter

When your air purifier's indicator light turns red, it's time to change the main filter. This typically occurs around 6 months of operation.




Step 1

Turn the air purifier off and unplug it. Rotate the top counter-clockwise to unlock and remove it.




Step 2

Remove the fabric pre-filter and the filter shelf ring. Note: Do not dispose the filter shelf ring.




Step 3

Use the filter handles to lift out the old filter and replace with new.



Step 4

Place the pre-filter back. Push the top cylinder down, rotate it clockwise to lock it.



Step 5

Press the button for 15 seconds until the light becomes white to reset the filter indicator.



Important! Do not wash the main filter. The main filter is not washable or reusable.

Disposal and recycling

This air purifier should be recycled as electronic waste. If you have any questions regarding the disposal of this air purifier, please contact your local authorities to ask for the correct method of recycling.